

Quick Setup Guide for Paradyne 6218 Wireless Modem

1. Refer to the included connection diagram to install the wireless router.
2. Reboot the PC to allow the PC to acquire an IP address from the router.
3. Open your web browser and in the address bar type <http://192.168.1.1>
4. Enter 'admin' for the username.
5. Enter 'admin' for the password, then hit 'OK'.
6. To setup the PPPoE which allows internet access:
 - Click 'Advanced Setup'
 - Click 'WAN'
 - Click 'Edit'
 - Click 'Next'
 - Click 'Next'
 - Enter your assigned username in the 'PPP username' box
 - Enter your assigned password in the 'PPP password' box
 - Click Next
 - Click Next
 - Click Save
 - Click Finish
7. The router will now reboot and login with your username and password.

Wireless Settings

Wireless networking is enabled by default. If you are not going to use wireless you may wish to disable this feature. To disable the wireless:

- Click 'Wireless'
- Click 'Basic'
- Uncheck the 'Enable Wireless' box
- Click the 'Save/Apply' button.

You may wish to use the wireless encryption options located in the 'security' section to secure your network.

For the complete user guide go to
<http://www.hay.net/upload/documents/6218-UserGuide.pdf>